



INSTRUCTION MANUAL

HARMONIC BALANCER BOLT KIT FORD POWER STROKE 6.0L & 6.4L

PART NUMBER CP239

1. Clean all parts thoroughly, including bolt threads and the end of the crankshaft, to remove all dirt and foreign oils.
2. Spread the assembly lubricant included in the package on the threads, underneath the bolt head, and the face of the washer that makes contact with the balancer bolt.
3. Then, install the bolt hand-tight, and tighten the bolts to **90 ft-lbs.**



SCAN ME

NEED HELP?

For technical support, please email:
tech@xotic-performance.com



SCAN ME

WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us
in your picture for a chance to be featured!

XOTICPERFORMANCE