

**XOTIC**<sup>®</sup>  
PERFORMANCE



**KIT INCLUDES**



**8 X** ROD BOLTS



**1 X** FASTENER ASSEMBLY LUBRICANT



**1 X** SOCKET

# INSTRUCTION MANUAL

## CONNECTING ROD BOLT KIT FOR 3.9L DODGE CUMMINS 4BT

PART NUMBER CR100 | 1983-1998

**STEP 1:** Clean all bolts, threads, and mating surfaces thoroughly to remove dirt, debris, or oil. Inspect connecting rods, caps, and bearings for cracks, wear, or damage. Replace any questionable parts before assembly.

**STEP 2:** Use only the supplied fastener lubricant. Apply evenly to the threads and under the bolt head for consistent clamping force.

**STEP 3:** Install bearings and pistons according to manufacturer guidelines. Seat the connecting rods onto the crankshaft, ensuring they are aligned in the same orientation as removed.

**STEP 4:** Hand-thread each bolt until snug. Verify the caps and rods are correctly aligned and fully seated.

**STEP 5:** Tighten bolts in a progressive sequence:

1. Snug each bolt to **10 ft-lbs.**
2. Final tighten to **95 ft-lbs.**

**STEP 6:** Re-check all fasteners for uniform torque or stretch. Document the original free length of each bolt for future comparison.

**STEP 7:** At teardown, measure each bolt against its original length. If a bolt has stretched more than 0.001", or shows any galling/damage, replace it immediately.



SCAN ME

### NEED HELP?

For technical support, please email:  
[tech@xotic-performance.com](mailto:tech@xotic-performance.com)



SCAN ME

### WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us.  
\*If your post has a chance to be featured!

#XOTICPERFORMANCE