

**XOTIC**<sup>®</sup>  
PERFORMANCE



# INSTRUCTION MANUAL

## FLEXPLATE BOLT KIT FOR FORD POWER STROKE 6.7L

PART NUMBER FP102 | 2011 - 2023

1. When installing the flexplate bolt kit, use the supplied washers and ensure they are installed with the chamfered side facing the underside of the bolt head.
2. Apply the provided assembly lubricant to the underside of the bolt head and washer contact surface.
3. Position the flexplate onto the crankshaft flange and install all bolts, tightening them by hand only until seated.
4. Using a crisscross pattern, torque the bolts evenly in stages to a final torque value of **95 ft-lbs.**



SCAN ME

### NEED HELP?

For technical support, please email:  
[tech@xotic-performance.com](mailto:tech@xotic-performance.com)



SCAN ME

### WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us  
in your picture for a chance to be featured!

#XOTICPERFORMANCE