



INSTRUCTION MANUAL

6.6L DURAMAX FLYWHEEL BOLT KIT

PART NUMBER FW100

1. Before installing any components, please check for any product damage, and report to us accordingly.
2. Apply Permatex Medium Strength Threadlocker BLUE to the threads of each flywheel bolt to prevent them from loosening due to vibration.
3. Use the provided assembly lubricant to lubricate under the head of each bolt. This will reduce friction and allow for accurate torque readings.
4. Finally, place the flywheel onto the crankshaft, tightening the bolts by hand. Proceed to torque the bolts to **250 ft-lbs** using a cross pattern for even distribution of pressure.



NEED HELP?

For technical support, please email:
tech@xotic-performance.com



WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us
in your picture for a chance to be featured!

#XOTICPERFORMANCE