



# INSTRUCTION MANUAL

## FLYWHEEL BOLTS FOR CHEVROLET & FORD (7/16" DIAMETER)

PART NUMBER FW101

1. Before installing any components, please check for any product damage, and report to us accordingly.
2. Use the provided assembly lubricant to lubricate under the head of each bolt. This will reduce friction and allow for accurate torque readings.
3. Finally, place the flywheel onto the crankshaft, tightening the bolts by hand. Proceed to torque the bolts to **90 ft-lbs** using a cross pattern for even distribution of pressure.



SCAN ME

### NEED HELP?

For technical support, please email:  
[tech@xotic-performance.com](mailto:tech@xotic-performance.com)



SCAN ME

### WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us in your picture for a chance to be featured!

[#XOTICPERFORMANCE](#)