

INSTRUCTION MANUAL

FLYWHEEL BOLT KIT FOR FORD POWER STROKE 6.0L & 6.4L

PART NUMBER FW104

1. Before installing any components, please check for any product damage, and report to us accordingly.
2. Use the supplied washers and ensure they are installed with the chamfered side facing the underside of the bolt head.
3. Use the provided assembly lubricant to lubricate under the head of each bolt. This will reduce friction and allow for accurate torque readings.
4. Finally, place the flywheel onto the crankshaft, tightening the bolts by hand. Proceed to torque the bolts to **70 ft-lbs** using a cross pattern for even distribution of pressure.



SCAN ME

NEED HELP?

For technical support, please email:
tech@xotic-performance.com



SCAN ME

WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us
in your picture for a chance to be featured!

#XOTICPERFORMANCE