

INSTRUCTION MANUAL

4.8L 5.3L 6.0L 6.2L CHEVROLET GEN III LS HEAD BOLT KIT 12 PT


PART NUMBER XP988 | 2003 & EARLIER

GET TO ACTION!

1. Before installing any components, please check for any product damage, and report to us accordingly.
2. Clean the threads in the block prior to installing the bolts to ensure proper fitment and accurate torque readings. You may purchase our thread chasers separately by searching [CS324](#) and [CS317](#) in our catalog.
3. Clean the washer seating areas on the cylinder head using a fast-evaporating solvent like non-chlorinated brake cleaner to remove oil, grease, and contaminants. Ensuring a clean surface is essential for achieving proper fastener preload.
4. Install the head gasket and cylinder head.
5. Seat the washers on the cylinder head. Ensure that the chamfered side of the washer faces upward (toward the bolt head).
6. Inspect for any misalignment.
7. Using the fastener assembly lubricant included in the package, apply lubricant to the threads of each head bolt, and the underside of the bolt heads.
8. Hand-tighten the bolts until they are snug.
9. Using the torque recommendations below, tighten the bolts in the following sequence:

**11MM BOLTS 1-10 TO 25 FT-LBS,
THEN TO 50 FT-LBS, AND FINALLY TO 75 FT-LBS.**

8MM BOLTS 11-15 TO 30 FT-LBS



KIT INCLUDES

 **30 X** HEAD BOLTS

 **30 X** HARDENED PARALLEL WASHERS

 **1 X** FASTENER ASSEMBLY LUBRICANT

 **2X** SOCKETS



SCAN ME

NEED HELP?

For technical support, please email:
tech@xotic-performance.com



SCAN ME

WORKING ON AN EXCITING NEW PROJECT?

Show off your craft on Instagram and tag us
in your picture for a chance to be featured!

[@XOTICPERFORMANCE](#)